




Kahler 2300/7300 Series Installation Instructions

For 6-10 String Flat Mount Tremolo Bridges (Non Multi-Scale)

Models: 2300, 2305, 2310, 2315, 2320, 2325, 2317, 2318, 2327, 2328, 2329, 2331, 7300,
7327, 7328



Questions? Contact us:

<https://kahlerusa.com>

info@kahlerusa.com



(702) 997-3049

INSTALLATION INSTRUCTIONS

FOR TREMOLO BRIDGES 2300, 2310, 2315, 2320
 SIX STRING SERIES





- X**: LOCATION OF (2) FRONT MOUNTING HOLES (USE CENTERLINE OF FRETBOARD).
SCALE LENGTH MEASUREMENT FOR CORRECT INTONATION IS FROM CRITICAL CONTACT POINT (CCP) AT NUT AND TO THE CENTER OF SADDLE TRAVEL (CST).
- Y**: LOCATION OF (2) REAR MOUNTING HOLES (USE CENTERLINE OF FRETBOARD)
ALIGNMENT LEFT & RIGHT FOR CORRECT STRING LOCATION ON FRETBOARD. (NOTE: L-R SADDLE ADJUSTMENTS ON BRIDGE).




DWG is to offer assistance to a qualified Luthier. We do not guarantee 100% satisfaction on this DWG, therefore the Luthier is 100% responsible for the measurements and routings.			
KAHLER INTERNATIONAL INC.			
TITLE: LOCATION MEASUREMENTS ASSY: 2300, 2310, 2315, 2320			
DWG. NO.		6200RIMA	
DRAWN: TASC	DATE: 03/21/11	SCALE: 1:1	

LOCATION FOR ROUTING SHAPE AND DEPTH FOR
CORRECT CAM AND SPRING ACTION



Z:3

BRIDGE MOUNTING PLATE LOCATION AND
 HEIGHT MEASUREMENT FOR **CORRECT STRING ACTION**



.500±.020 NOMINAL HEIGHT. IF GREATER, ADJUST NECK ANGLE OR ADD SHIMS UNDER BRIDGE PLATE.
 IF LESS, ADJUST NECK ANGLE OR ROUTE AN INSET.


DWG is to offer assistance to a qualified Luthier. We do not guarantee 100% satisfaction on this DWG, therefore the Luthier is 100% responsible for the measurements and routings. "A GUIDE ONLY"			KAHLER INTERNATIONAL INC.		
TITLE: ROUTING/FRET HT. MEASUREMENTS ASSY: 2300, 2310, 2315, 2320			DWG. NO. 6200RIMA		
DRAWN: TASC	DATE: 03/21/11	SCALE: 1:1			

INSTALLATION INSTRUCTIONS

FOR TREMOLO BRIDGES 2317, 2318, 2327, 2328
 7 & 8 STRING SERIES





- X** : LOCATION OF (2) FRONT MOUNTING HOLES (USE CENTERLINE OF FRETBOARD).
SCALE LENGTH MEASUREMENT FOR CORRECT INTONATION IS FROM CRITICAL CONTACT POINT (CCP) AT NUT AND TO THE CENTER OF SADDLE TRAVEL (CST).
- Y** : LOCATION OF (2) REAR MOUNTING HOLES (USE CENTERLINE OF FRETBOARD)
ALIGNMENT LEFT & RIGHT FOR CORRECT STRING LOCATION ON FRETBOARD. (NOTE: L-R SADDLE ADJUSTMENTS ON BRIDGE).




DWG is to offer assistance to a qualified Luthier. We do not guarantee 100% satisfaction on this DWG, therefore the Luthier is 100% responsible for the measurements and routings.				KAHLER INTERNATIONAL INC.			
				TITLE: LOCATION MEASUREMENTS ASSY: 2300, 4300, 7300			
DWG. NO. 6205RIMA				DRAWN: TASC			
				DATE: 05/23/12		SCALE: 1:1	

LOCATION FOR ROUTING SHAPE AND DEPTH FOR CORRECT CAM AND SPRING ACTION



Z:3

BRIDGE MOUNTING PLATE LOCATION AND HEIGHT MEASUREMENT FOR **CORRECT STRING ACTION**



<p>DWG is to offer assistance to a qualified Luthier. We do not guarantee 100% satisfaction on this DWG, therefore the Luthier is 100% responsible for the measurements and routings. "A GUIDE ONLY"</p>	<p style="text-align: center;">KAHLER INTERNATIONAL INC.</p> <p>TITLE: ROUTING/FRET HT. MEASUREMENTS ASSY: 2317, 2318, 2327, 2328</p> <p>DWG. NO. 6205R1MA</p> <p>DRAWN: TASC DATE: 03/21/11 SCALE: 1:1</p>
----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------


INSTALLATION INSTRUCTIONS

FOR TREMOLO BRIDGES 2329, 2331
 9 & 10 STRING SERIES





X : LOCATION OF (2) FRONT MOUNTING HOLES (USE CENTERLINE OF FRETBOARD).
SCALE LENGTH MEASUREMENT FOR CORRECT INTONATION IS FROM CRITICAL CONTACT POINT (CCP) AT NUT AND TO THE CENTER OF SADDLE TRAVEL (CST).

Y : LOCATION OF (2) REAR MOUNTING HOLES (USE CENTERLINE OF FRETBOARD)
ALIGNMENT LEFT & RIGHT FOR CORRECT STRING LOCATION ON FRETBOARD. (NOTE: L-R SADDLE ADJUSTMENTS ON BRIDGE).




DWG is to offer assistance to a qualified Luthier. We do not guarantee 100% satisfaction on this DWG, therefore the Luthier is 100% responsible for the measurements and routings.			
KAHLER INTERNATIONAL INC.			
TITLE: LOCATION MEASUREMENTS ASSY: 2329, 2331			
DWG. NO. 6206RIMA			
DRAWN: TASC	DATE: 05/23/12	SCALE: 1:1	

LOCATION FOR ROUTING SHAPE AND DEPTH FOR
CORRECT CAM AND SPRING ACTION



Z:3

BRIDGE MOUNTING PLATE LOCATION AND
 HEIGHT MEASUREMENT FOR **CORRECT STRING ACTION**



DWG is to offer assistance to a qualified Luthier. We do not guarantee 100% satisfaction on this DWG, therefore the Luthier is 100% responsible for the measurements and routings. "A GUIDE ONLY"	KAHLER INTERNATIONAL INC.		
	TITLE: ROUTING/FRET HT. MEASUREMENTS ASSY: 2329, 2331		
	DWG. NO. 6206RIMA		
	DRAWN: IASC	DATE: 03/21/11	SCALE: 1:1